


## How to add additional remote controllers to work with alarm panel?



Please short press the **learning** button, the Wireless signal LED indicator will be on, and then long pressing any one button on the remote controllers for 3s, when **wireless signal LED indicator** goes out, it means adding successfully. At this moment, please press **Arm/disarm** button for double-test. Every press on the remote controller, the **wireless signal LED indicator** will blink once as well as the alarm host will make beep sound “di” or “di di” to confirm that it receives the command from remote controllers.